



Instructions For Use
MTM002-IFU

Revision: 2

Page 1 of 2

P.O. Box 3286 - Logan, Utah 84323, U.S.A. - Tel. (800) 729-8350 - Fax (435) 755-0015 - www.scytek.com

Mouse To Mouse HRP Ready-To-Use

Rev. Date: 10/28/03

Species of Origin:GoatAntigen Specificity:Anti-Polyvalent (Mouse, Rat, Rabbit and Guinea Pig)Enzyme Conjugate:PeroxidaseChromogen Substrate:3-Amino-9-Ethylcarbazole (AEC)

Procedure:

- 1. Deparaffinize and rehydrate tissue section.
- 2. To reduce nonspecific background staining due to endogenous peroxidase, incubate slide in hydrogen peroxide for 10-15 minutes.
- 3. Wash 2 times in buffer.
- 4. If required, incubate tissue in digestive enzyme.
- 5. Wash 4 times in buffer.
- 6. Apply Super Block (blue cap), and incubate for 5 minutes at room temperature to block nonspecific background staining. **Note:** Do not exceed 10 minutes or there may be a reduction in desired stain.
- 7. Wash 1 time in buffer.
- 8. Apply Mouse To Mouse Block and incubate 10-60 minutes. Incubation time is dependent on the amount of endogenous Ig found in the tissue type.
- 9. Rinse 4 times in buffer.
- 10. Apply primary antibody and incubate according to manufacturer's protocol.
- 12. Wash 4 times in buffer.
- 13. Apply UltraTek Anti-Polyvalent (yellow cap), and incubate for 10-20 minutes at room temperature.
- 14. Wash 4 times in buffer.
- 15. Apply UltraTek HRP (red cap), and incubate for 10-20 minutes at room temperature.
- 16. Rinse 4 times in buffer.
- 17. Add 2 drops (100ul) AEC Chromogen to AEC Substrate, mix by swirling and apply to tissue. Incubate for 5-15 minutes, depending on the desired stain intensity.
- 18. Counterstain and coverslip using a permanent mounting media

Troubleshooting Guide

Overstaining:

The material contained herein is the property of ScyTek Laboratories, Inc. and is confidential. Unauthorized use or copying is prohibited.

ScyTek Laboratories

		🍊 コスモ・バ	イオ株式会社
Instruct			
MTM			
Rev. Date: 10/28/03	Revision: 2	Page 2 of 2	

P.O. Box 3286 - Logan, Utah 84323, U.S.A. - Tel. (800) 729-8350 - Fax (435) 755-0015 - www.scytek.com

- 1. Concentration of the primary antibody was too high or the incubation time was too long.
- 2. Temperature during incubation was too high.
- 3. Incubation time with UltraTek Anti-Polyvalent or UltraTek HRP was too long.

Nonspecific Background Staining:

- 1. Rinsing between steps was inadequate.
- 2. Tissue was allowed to dry with reagents on.
- 3. Folds in tissue trapped reagents.
- 4. Inadequate blocking with Mouse To Mouse Block.
- 5. Tissue contains endogenous biotin.
- 6. Antigen migrated in tissue.
- 7. Excessive tissue adhesive on slides.
- 8. Inadequate blocking with Super block.

Weak Staining:

- 1. Primary antibody concentration was too low or incubation time was too short.
- 2. Reagents are past their expiration date.
- 3. Inadequate removal of wash water between steps, resulting in dilution of reagents.
- 4. Counterstain or mounting media were incompatible and dissolved the chromogen reaction product.
- 5. Room temperature was excessively cool.
- 6. The primary antibody does not recognize an antigen that survives fixation and embedding.
- 7. Excessive incubation with Super Block.

No Staining:

- 1. Steps were inadvertently left out.
- 2. There is no antigen in the tissue.
- 3. The primary antibody is not of mouse, rat, rabbit or guinea pig origin.
- 4. Chromogenic substrate has been replaced with another that is not intended for use with peroxidase.
- 5. One or more components of the kit have been inactivated.

The material contained herein is the property of ScyTek Laboratories, Inc. and is confidential. Unauthorized use or copying is prohibited.